

Jet Propulsion Laboratory California Institute of Technology

Trends in Radiation Performance of Modern Microprocessors and Microcontrollers

Steven M. Guertin steven.m.guertin@jpl.nasa.gov 818-321-5337 NASA/JPL

Acknowledgment:

This work was sponsored by: The NASA Electronic Parts and Packaging Program (NEPP)

California Institute of Technology. Government sponsorship acknowledged.

To be presented by Steven M. Guertin at NEPP ETW, June 14, 2016.





- Microcontrollers and Microprocessors
- Some Radiation Effects Data
- Test equipment issues
- Technology impact SRAMs and Logic
- Some Trends
- Future Work

Our goal is to explore test methods and efforts to try to extract trends that can be exploited to improve radiation testing of these devices.



• Microprocessors are

- The central processing unit (CPU) of a computer
- Part of a system with RAM, ROM, and other peripherals
- Intended for general operations that may not be defined at time of build – open-ended
- Microcontrollers are
 - More varied in internal technologies than processors
 - Usually used in embedded systems
 - Contain most of the circuitry necessary to implement a computer – may be called mini-computers
 - Have RAM and ROM on-board, along with peripherals
 - Usually provide well-defined application functionality
- Both get referred to as SOCs story for another time...
 - The names are sometimes used interchangeably...

Commercial Trends

NASA

- Clarify what we're talking about
 - Shrinking features
 - Increasing complexity
- Recently, microprocessors are getting more complex, not faster, not higher power
- Microcontrollers are a little different because they mix multiple technologies



Hruska, 2012, The death of CPU scaling: From one core to many — and why we're still stuck, http://www.extremetech.com/

Microcontollers and Microprocessors in Space



• Performance

- Latest flattening due to focus on efficiency...
- Until about 2000, space processors were "close" to commercial devices.
- BAE's RAD55XX series will bump up a bit.

Deployed devices in space missions



-Information adapted from www.cpushack.com





For microprocessors and microcontrollers:

- Total Ionizing Dose (TID) can cause:
 - Slower switching eventually unreliable and won't "boot"
 - Data loss on-chip ROM degradation
 - Reduced drive current at outputs
 - Slower I/O
- Single Event Effects (SEE)
 - CMOS devices may show single event latchup (SEL)
 - For devices with on-chip power handling, gate rupture or burnout (SEGR or SEB) may be a risk
 - But mostly, these devices are affected by single event upsets and transients (SEU) and (SET) that can cause incorrect operations or bit flips
 - When it leads to incorrect operation, the event is often called a single event functional interrupt (SEFI)

Rad Data Example Atmel AT91SAM9G20

NASA

- Heavy ion tests of AT91SAM9G20
 - 90 nm "microprocessor" typically used as a "microcontroller"
- Target was the On-chipmemory (OCM)
 - Per last slide OCM bits similar to leading cause of device errors.
 - (This is most likely to cause errors during execution – and bits are expected to be similar to CPU registers and caches)
- Same data obtained using hardware debugging, and insitu test code.





National Aeronautics Current Efforts: and Space Administration Freescale P2020 – 1 of 5

- P2020 Processor is a Freescale 45 nm dual e500 core microprocessor with many built-in features
- L1 and L2 caches are the most sensitive structures on the device.
- Unless L1 is operated in "write-through", L1 bit upsets will cause threads to crash...
 - Usually ~50% or more such threads will kill the operating system.
- Dynamically, block errors may dominate
 - Causes data errors

2015/2016 Effort in collaboration with Jeff George – Aerospace Corp.





National Aeronautics Current Efforts: and Space Administration Freescale P2020 – 2 of 5



L1 Errors will cause app/OS crash unless in "write-through"

Bit errors are per-bit.

L1 bit errors are about 10x worse than block errors - 5×10⁵ bits

- L2 is 100x worse

L2 block errors not tested but bit errors are EDACprotected

-Error Detection and Correction



To be presented by Steven M. Guertin at NEPP ETW, June 14, 2016.

National AeronauticsAnother Example:and Space AdministrationFreescale P2020 - 3 of 5



Board – to – Board / Part – to – Part Variation…



Another Example: Freescale P2020 – 4 of 5



- Ethernet Testing
- No corrupt packets observed
 - 768-byte payload
 - 44 Mbps rate
- While testing for packet corruption, sensitivity limited by device crashes
 - unrelated to Enet
- Packet loss about the same in/out of beam ~ 0.01-0.1%

1.E-3 1.E-4 1.E-5 1.E-6 1.E-7 1.E-8 1.E-9 1.E-10 1.E-11 1.E-12 1.E-13 1.E-14 Cannot test packets here

due to crash interference

30

LET (MeV-cm²/mg)

40

50

Ethernet Sensitivity - Crashes

Cross Section (cm²/device; cm²/packet)

1.E-15 1.E-16

1.F-17

0

10

20

60

Another Example: Freescale P2020 – 5 of 5



- Showed cache and Ethernet sensitivity
 - New and old data similar, but with emphasis on dynamic test
 - Ethernet data limited by crash rate
- In FY16, we have expanded test data on P2020
 - 3 proton tests, 2 heavy ion tests 6 boards tested (one device per board)
 - L1/L2
 - Flash memory controller
 - Ethernet
 - Register testing with and without debugger
- Repeatability between all devices with some variation on certain data at ~30-40%.
 - No dramatic differences, including new and old devices

How To Test These



• Hardware setup



• Some Notes:

- For SEE testing, In-Situ operation is required
- Often the cost of an evaluation board is lower than the cost of preparing a DUT for testing
- 3rd Party Remote testing is only viable for TID or post-SEE device reliability testing
 - It is also effective to convert a manufacturer's burn-in bias board, rather than build a new one

Eval Board Issues...



- We are finding some significant problems with some test boards, in terms of preparation for test...
- Package on package may become a significant problem... (May only apply to microprocessors)





To be presented by Steven M. Guertin at NEPP ETW, June 14, 2016.

SRAM Scaling







To be presented by Steven M. Guertin at NEPP ETW, June 14, 2016.

- This is great data, but it is FIT/MB, which doesn't correlate directly to space data...
- Proton and Muon sensitivity are becoming more important at smaller sizes – primarily due to reduced critical charge and sensitivity to direct ionization from particles with a charge of ± 1 .
- All technologies show flat trend down to 28nm, but perhaps sensitivity is actually increasing below that.
 - Space community worried about a possible increase since around 65nm is it coming?



Hubert, Integration, The VLSI Journal, Jan 2015)

- Comparison of available data several reports.
 - Including both microprocessors and microcontrollers
 - Heavy ion saturated cross section
- No clear trend is evident in saturated cross section as a function of feature size.

Rad Effects Data Feature Size









- 10-15 years ago logic sensitivity started to be a significant source of SER
- However, for a running circuit, logic masking is very important
 - E.g. processors (in both types of devices) are generalpurpose, and on each clock cycle executes a few out of 100s-1000s of possible instructions
 - During execution of a set of instructions, the logic for unused instructions is masked.
- Testing for this requires operating the device...
 - Amount of logic and logic masking depends on device type and peripherals.



Realistically, it is difficult to know the highest possible logic utilization. Thus it is important to think of possible system use when designing a test.



National Aeronautics

and Space Administration

– Sitting in the Mrad(Si) range now – this is a high bar... But integration of multiple component types, including on-chip regulation and higher-voltage IOs, bipolar

Generally, scaling is very good to TID

circuits, etc., threaten this TID performance

Microcontrollers

Microprocessors

performance but...

- These are currently somewhat TID limited already (at least commercially) – 10-20krad(Si) is common
- There are multiple technologies in these devices, including bipolar, charge pumps, etc.
- There is no reason to think that these devices will gain benefit from scaling of some portions when others will not scale and may remain the same or get worse.

18





Trends Going Forward



Notional Trends for Microcontrollers and Microprocessors

croprocessors	Test Equipment	Custom Boards	Eval Boards
	TID	Very Good	Getting Worse
	SEL	Going Away	Still a Risk
	SRAM SEE	Going Away	Still a Risk
	Logic SEE	Staying Low	Becoming Risk
	Protons	Staying Same	Becoming Risk
	Integration	Staying Same	Increasing
₹	Access To Info	Easier	Harder
_	Technology Variety	Reducing	Increasing

Microcontrollers	Test Equipment	Custom Boards		/al Boards	σ
	TID	Getting Better		etting Worse	
	SEL	Going Away	St	till a Risk	g
	SRAM SEE	Going Away	St	till a Risk	<u> </u>
	Logic SEE	Going Away	G Contraction of the second se	etting Worse	
	Protons	Staying Same	B	ecoming Risk	D
	Integration	Staying Same		creasing	Ř
	Access To Info	Easier	н	arder	
_	Technology Variety	Reducing		creasing	

Differences here are primarily due to the mix of sub components in each device type. Also, microcontroller processors tend to be older technology.

To be presented by Steven M. Guertin at NEPP ETW, June 14, 2016.

National Aeronautics

and Space Administration





- Snapdragon Samsung 14nm LPP
 - Have test boards
 - All parts are package on package
 - Boot sequence difficult to work with
 - Vendor instructed to burn debug connections in chip
 - Collaboration with Crane, GSFC
- Intel 14nm
 - Ongoing, but good data reported by GSFC and Crane recently
 - Collaboration with Crane, GSFC
- P5040/RAD55XX
 - Leverage earlier P5020 work







- Snapdragon Samsung 14nm LPP
 - Have test boards
 - All parts are package on package
 - Boot sequence difficult to work with
 - Vendor instructed to burn debug connections in chip
 - Collaboration with Crane, GSFC
- Intel 14nm
 - Ongoing, but good data reported by GSFC and Crane recently
 - Collaboration with Crane, GSFC
- P5040/RAD55XX
 - Leverage earlier P5020 work







- The main thing is: is my mission going to do something incorrectly because of my microprocessor or controller?
 - TID and SEL must be considered unless a compelling technology reason is known
 - The general approach of bounding the problem has traditionally been performed by studying memory cells
- Memory cell scaling appears to be impacting SER in a way that will start impacting commercial devices.
- Due to increasing complexity and integration...
 - It is necessary to functionally operate devices to determine possible logic sensitivity increase
 - Test boards and hardware efforts continue to evolve
- Thus far there is no clear indication of scaling impact or trends moving forward. However, this work has informed future work, which will:
 - Extend test methods to newer devices and architectures
 - And explore possible scaling issues related to memory cells and logic sensitivity
- More processor data coming soon

Acknowledgement



- This work was funded by the NASA Electronic Parts and Packaging Program (NEPP)
- Special thanks for collaborative discussions with several teams:
 - Adam Duncan & NSWC Crane folks
 - Carl Szabo and Ken LaBel, GSFC
 - Jeff George, Aerospace Corporation
 - Larry Clark, ASU
 - Heather Quinn, LANL, and other members of the Microprocessor and FPGA Mitigation Working Group
 - Mehran Amrbar and Sergeh Vartanian, JPL



Backup

To be presented by Steven M. Guertin at NEPP ETW, June 14, 2016.

1997 - Pathfinder



- The Pathfinder mission is a microcontroller / microprocessor hybrid application
- Rover device used was 80C51
 - RAM, ROM, IO, and other features
 - (Microcontroller)
- The 80C51 would send data to the RAD6000 computer on the pathfinder base.

. (Device usage per Lloyd Keith: http://quest.arc.nasa.gov/mars/ask/about-mars-path/pathfinder_computer.txt)

- Rover was like an embedded system
- Base provided general computing



 The key here is that modern space missions commonly consist of microprocessors and microcontrollers at various performance points, as needed.





- Many different devices may be used today:
 - Microcontrollers for stand-alone instruments, wheel controllers, etc.
 - Low-to-Mid range microprocessors to enable high reliability operations at low power
 - High performance processors to handle large amounts of data.
- Architectures are exploding on us
 - ARM has moved the Microprocessor and Microcontroller markets significantly
 - There is still need to understand earlier architectures Sparc, Intel, PowerPC, etc.
 - Every architecture is growing with multiple functions on the chip, and the number of cores is increasing...
 - And some of these are working into Rad Hard devices



Rad Testing Trends



- TID may be better suited by building static-bias fixtures and sending devices to 3rd party testing
 - It is also effective to convert a manufacturer's burn-in bias board, rather than build a new one
- However, based on the previous table:
 - Reduction in custom-built systems for both types of devices
 - Increased reliance on evaluation boards
 - A great example is the P2020RDB the board is \$700, but buying P2020 parts individually is \$200
 - This trend is likely to continue but...